

SUNPROOF YOUR FENCE FOR \$200*

including tools



TOOLS YOU NEED

- 8L Taubmans® Sunproof in your chosen colour and gloss level
- Monarch 4' x 10' Double Strength Absorbent Drop Sheet
- Rocket Medium Sanding Block
- Bunnings 10L Pail Bucket
- Monarch Paint Stirrer with Can Opener
- Monarch 38mm Scraper
- Monarch 100mm Fence Brush
- Monarch 130mm 3 piece Fence, Deck & Pergola Kit
- Old scrub sponge or cloth/rag you have at home
- Detergent you have at home

MOST POPULAR FENCE COLOURS

Colorbond®
Monument®

Colorbond®
Pale Eucalypt®

Colorbond®
Classic Cream™

Colorbond®
Woodland Grey®

Colorbond®
Deep Ocean®

T&Cs apply, see taubmans.com.au/sunproof



SUNPROOF YOUR FENCE FOR \$200*

HOW TO SUNPROOF YOUR FENCE



1. Get your space ready

- Temporarily remove or cover pot plants, garden hoses and other items close to your fence. Pin back any trees or shrubs that lean on your fence.



2. Clean and prepare your fence

- Fill your bucket with water and detergent and dunk your sponge/cloth into the bucket. Clean your picket fence with your wet sponge/cloth to remove all dirt, cobwebs, and any other surface contamination. Wait until dry and then remove any loose/flaking paint with your scraper. Then sand your fence thoroughly with your sanding sponge and remove dust with a dry cloth or towel. These steps ensure maximum paint adhesion to the surface.
- Lay your canvas drop cloth on the ground along your fence. Open your can of Sunproof and stir the paint in a circular lifting motion for 5 minutes before use.



3. Paint your fence with 2 coats

- Good news! Sunproof is self priming so a primer is not required. For a beautiful finish, use two generous coats and three on bare timber. Apply paint from top to bottom and follow the picket direction.
- Firstly, using your fence brush, apply one coat of paint onto the side of the pickets and back rails as your roller won't reach here. Once complete, use your roller and evenly apply one coat on the front of the pickets. Paint each picket one by one and follow the picket direction. Always lift the roller as you reach the end of a stroke, reload your roller and continue where you lifted off.
- Once you have completed your first coat, wait 2 hours before applying the second. Apply the second coat following the same process. Keep the lid on the paint can when not in use.



4. Clean up

- Once your fence is dry, remove your drop sheet and place items from Step 1 back into their spots.
- Scrape excess paint into a separate container. Wash equipment with water. Please do not pour paint or wash water down drains or sewers. Paintback has collection sites across Australia where you can drop-off your unwanted paint and packaging for no extra charge. Please dispose contents and container in accordance with all local, regional, national and international regulations. Visit paintback.com.au for more information.



5. Admire your Sunproof fence